

Orange Tree Technologies

ZestSC1

User Guide

Author	Charles Sweeney and Matt Bowen
Version	1.06
Date	4 th December 2007

Version	Date	Comment
1.00	02/11/04	First Version
1.01	01/02/05	Clarifications for power supply and clocks
1.02	17/02/05	Resettable fuse ratings
1.03	07/03/05	Added 512 byte transfer restriction
1.04	28/04/05	Added Verilog support
1.05	14/03/06	Updated for LP USB interface
1.06	04/12/07	Added contents of shipping package Rubber feet supplied separately

© 2007 Orange Tree Technologies Ltd. All rights reserved. All trademarks and registered trademarks are the property of their respective owners. All specifications are subject to change without notice.

Disclaimer

This document provides outline information only. Orange Tree Technologies reserves the right to change this document without notice. Orange Tree Technologies makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, Orange Tree Technologies does not warrant the accuracy or completeness of the information, text, graphics, or other items contained in this document. Orange Tree technologies cannot accept any liability for loss or damages arising from the use of this manual or the use of products described in it.

Orange Tree Technologies products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use Orange Tree Technologies products in these types of equipment or applications. For all restrictions on use of Orange Tree Technologies products see Orange Tree Technologies Terms and Conditions of Sale.

1 Contents

1	CONTENTS.....	3
2	GLOSSARY.....	4
3	REFERENCES.....	4
4	INTRODUCTION.....	5
5	SYSTEM REQUIREMENTS	5
6	INSTALLATION.....	6
6.1	INTRODUCTION	ERROR! BOOKMARK NOT DEFINED.
6.2	HARDWARE	6
6.2.1	Headers	7
6.3	SOFTWARE	10
7	DESCRIPTION	11
7.1	USB	11
7.1.1	<i>Communications with Host</i>	13
7.2	FPGA.....	17
7.3	MEMORY.....	18
7.4	IO	20
7.5	LEDs	21
7.6	CLOCKS.....	22
7.7	POWER	22
7.8	BUILD OPTIONS	24
8	USING THE HOST LIBRARY.....	25
9	HOST UTILITIES.....	26
9.1	Bit2C.....	26
9.2	SETID.....	26
10	EXAMPLES	27
11	HOST LIBRARY FUNCTION REFERENCE.....	28

2 Glossary

DCI	Digitally Controlled Impedance
DCM	Digital Clock Manager
Endpoint	A USB endpoint is the source or destination of a USB transfer
GPIF	General Programmable Interface of the USB controller
SIE	Serial Interface Engine for USB
UCF	User Constraints File
USB	Universal Serial Bus

3 References

1. Cypress Semiconductor Corporation, CY7C68013 EZ-USB FX2 USB Microcontroller High-speed USB Peripheral Controller, Rev C, 19th December 2002.
2. Cypress Semiconductor Corporation, GPIF Designer, Version 1.0.0.6, 2003.
3. Cypress Semiconductor Corporation, EZ-USB FX2 Technical Reference Manual, Version 2.2, 2003.
4. Cypress Semiconductor Corporation, EZ-USB FX2 GPIF Primer, 29th April 2003.
5. Cypress Semiconductor Corporation, Introduction to the EZ-USB FX2 GPIF Engine, 29th May 2002.
6. Cypress Semiconductor Corporation, CY7C1356B 512K x 18 Pipelined SRAM with NoBL Architecture, Rev A, 27th August 2003.
7. Cypress Semiconductor Corporation, CY7C1472V33 4M x 18 Pipelined SRAM with NoBL Architecture, Rev C, 16th June 2004.
8. Xilinx Inc., Synthesisable 200MHz ZBT SRAM Interface, XAPP136 V2.0, 10th January 2000.

4 Introduction

Thank you for purchasing a ZestSC1. This user guide explains how to install the ZestSC1 and how to start using it with some examples. Please read this guide fully before starting to use the ZestSC1.

5 System Requirements

1. A host computer or USB hub with an available USB port. The USB port may be either Full Speed 12Mbps (USB V1.1 or 2.0) or High Speed 480Mbps (USB V2.0).
2. Windows 2000 or Windows XP operating system.
3. Space about 150 x 150 mm on a desk or bench near the host computer for placing the board.
4. Operating ambient temperature range 0 to +40 deg C.
Storage ambient temperature range -40 to +85 deg C.
5. ZestSC1 can be either bus-powered (power is drawn from the USB port) or self-powered (power is drawn from either a PC hard disk power connector or a mains power wall adapter (not supplied unless ordered separately)).
 - a) **If the USB port is to be used to supply power (ZestSC1 is bus-powered) then it must be a high power (500mA) port.** Most computer USB ports are high power but see paragraph i) below for how to determine the power rating of a USB port. For USB hubs see paragraph ii) below. A high power USB port provides 2.5W. The quiescent power of ZestSC1 is given in the section titled Power.
 - i) To determine the power rating of a computer USB port, do the following:
 - (1) Go to Control Panel -> System -> Hardware -> Device Manager -> Universal Serial Bus Controllers.
 - (2) Right click a USB Root Hub, then go to Properties -> Power.
 - (3) Under Hub information, Total power available should be 500mA per port.
 - (4) Repeat for all USB Root Hubs.
 - ii) **If ZestSC1 is to be bus-powered use only self-powered USB hubs with high power (500mA) ports.** Bus-powered USB hubs generally have only low power (100mA) ports and should be used only if ZestSC1 is self-powered. The documentation for your USB hub should give the power rating of the ports.
 - b) If more than 2.5W of power is required then a PC hard disk power connector or a mains power wall adapter can be used to make the board self-powered. The wall adapter should be switch mode with low ripple and have an output voltage between 3.5V and 5.5V (nominally 4.5V or 5.0V), an output current of at least 1A, and a female plug inner diameter of 2.5mm. **The plug from the wall adapter should have +5V power on the outside of the pin and ground on the inside of the pin.**

6 Installation

6.1 Packing List

Please check that the following items are in the package sent to you and contact Orange Tree Technologies if any are missing:

1. ZestSC1 card in anti-static bag
2. Four self-adhesive rubber feet in the same anti-static bag as the card
3. ZestSC1 Support Software CD
4. USB cable
5. Installation Instructions printed sheet
6. Known Issues printed sheet
7. Power supply wall adapter, if ordered

Please read fully and then follow these installation instructions.

6.2 Hardware

1. Check that your target system in which ZestSC1 will be used meets the system requirements of the previous section.
2. **Ideally all these installation operations should be performed in an anti-static environment with an anti-static workbench and anti-static wrist-straps. Alternatively if this is not possible you should earth yourself regularly during installation by touching an unpainted earthed metal surface.**
3. If required, stick the self-adhesive rubber feet in the four corners of the board.
4. Place the board on a flat surface close enough to the host PC so that the USB cable reaches between them.
5. Set the jumpers as required – see the Headers section. The board is supplied with the default settings, which should be sufficient for getting going initially.
6. If the board is to be self-powered then one of the following two options should be used:
 - a) Optional. If a mains power wall adapter is to be used, plug it into the board with the adapter switched off and then switch on the adapter. This prevents voltage ringing in the cable. **The plug from the mains power adapter should have +5V power on the outside of the pin and ground on the inside of the pin.** When the plug is inserted in the jack, power from USB is disconnected by the jack.
 - b) Optional. If a PC hard disk power connector is to be used, plug it into the board with the power source switched off and then switch on the power source. The PC hard disk drive power connector is intended for use of the board inside a PC and the board should be mounted securely using the four corner holes and insulating

standoffs in a position where it cannot touch any other items such as chassis, boards or cables.

7. Plug the USB cable into ZestSC1 and the host computer or USB hub. It does not matter whether the host computer is switched on or off. The cable has different connectors at each end to ensure it is plugged in the correct way round.
8. If the host computer is switched off then switch it on now.
9. The host computer will detect a new USB device and request the software driver.
10. Install the software driver – see section 6.2 Software.

6.2.1 Headers

The connectors and headers on the board are listed below. Their approximate positions are shown in Figure 1.




Figure 1. Approximate Positions of Connectors and Headers

Pin numbers zig-zag along the two-row header as shown in Figure 2.




Figure 2. Zig-Zag Pin Numbering of Two-Row Header

Unless otherwise stated, pin 1 is indicated on the PCB by the figure '1'.

J1 USB B connector

J2 Test header for monitoring USB controller signals:

Pin	USB Controller Signal
1	Port E bit 0
2	Port E bit 1
3	Port E bit 2
4	BreakPoint

J3 JTAG header for configuring FPGA:

Pin	FPGA JTAG Pin
1	VCC 2.5V
2	Ground
3	TCK
4	TDO
5	TDI
6	TMS

J4 User I/O Header

IO pins are connected directly to the FPGA. See UCF for FPGA pin connections.

Signal	Pin	Pin	Signal
5V	1	2	3.3V
Ground	3	4	Ground
Ground	5	6	Ground
Ground	7	8	Ground
IO0	9	10	IO1
IO2	11	12	IO3
IO4	13	14	IO5
IO6	15	16	IO7
IO8	17	18	IO9
IO10	19	20	IO11
IO12	21	22	IO13
IO14	23	24	IO15
IO16	25	26	IO17
IO18	27	28	IO19
IO20	29	30	IO21
IO22	31	32	IO23
IO24	33	34	IO25
IO26	35	36	IO27
IO28	37	38	IO29
IO30	39	40	IO31
IO32	41	42	IO33
IO34	43	44	IO35
IO36	45	46	IO37
IO38	47	48	IO39
IO40	49	50	IO41
IO42	51	52	IO43
IO44	53	54	IO45
CLK_IO_P	55	56	CLK_IO_N
IO46	57	58	Ground
Ground	59	60	Ground
Ground	61	62	Ground
Ground	63	64	Ground

J5 2.5 mm power jack for mains adapter

Pin	Signal
Centre socket contact - 1	Ground
Switched input pin - 2	VBUS (5V from USB)
Outer socket contact - 3	3.5V to 5.5V POWER IN

When a plug is not inserted, pin 2 VBUS is connected to the jack output pin 3.

When a plug is inserted, the outer contact is isolated from pin 2 and connects the plug outer contact to the jack output pin 3.

J6 Power source

Connect Pins	Power Source
1-2	Power jack J5 or USB
2-3	Hard disk drive connector J7

J7 PC hard disk power connector

Pin	Signal
1	No connect
2	Ground
3	Ground
4	5V

6.3 Software

The software driver package includes a Windows Installer utility to perform the installation. To install the software, run the setup.exe utility from the CD and follow the on-screen instructions. The software will be installed in the following directory structure:

Directory	Contents
Docs	Product documentation including the User Guide (this document)
Driver	Driver binary and installation (INF) files
Examples	Examples for host and FPGA code showing how to use various features of the ZestSC1
Inc	Host support library C include file
Lib	Host support library C static library file
Utils	Contains utilities to set the card ID on a board (setid.exe) and convert FPGA configuration files to C header files (Bit2C.exe)
Verilog	Verilog FPGA files for interfacing to the USB controller and SRAM
VHDL	VHDL FPGA files for interfacing to the USB controller and SRAM

7 Description

The block diagram of ZestSC1 is shown in Figure 3. It is a desktop board with a Xilinx Spartan-3 FPGA with up to one million system gates. The FPGA is connected to a host computer over High Speed USB (12 or 480Mbps/sec) for configuration and data communication. A synchronous SRAM of either 1 or 8 MBytes stores application data, and a 32x2 0.1" pitch header can be used for I/O.




Figure 3. ZestSC1 Block Diagram

7.1 USB

ZestSC1 is a USB device and needs to be connected to a USB host computer. It can draw power from the USB cable or from a mains power adapter, according to the position of J6. The USB port may be either Full speed 12Mbps (USB V1.1 or 2.0) or High speed 480Mbps (USB V2.0).

The USB controller is the Cypress EZ-USB FX2 USB Microcontroller [1]. It includes an 8051 microcontroller that is used for enumeration and board management firmware. The 8051 address and data buses are connected to the FPGA. The USB controller is implemented entirely in hardware. The ZestSC1 comes fitted with an EEPROM containing firmware to communicate with the supplied host driver. It is strongly recommended that this firmware is not modified and that the supplied host driver and FPGA cores are used for all designs. Failure to do so may result in damage to the hardware.

The main method for data communication between the FPGA and USB is by the FX2's FIFO interface. This can operate with its data bus 8 or 16 bits wide and at a frequency of 48MHz giving a maximum burst data rate of 96 MBytes/sec.. It is used for configuring the FPGA from the host computer and for data communications between the FPGA and host computer. The FX2 Serial Interface Engine SIE, which controls USB transfers, uses

the FIFO interface. The FIFO interface can be controlled by either an internal master in the FX2 or an external master in the FPGA. The internal master is a programmable state machine called the General Programmable Interface or **GPIF**. Conversely, when the FIFO interface is controlled by the FPGA it is in **Slave FIFO** mode.

There are also general purpose data ports connected between the FX2 and the FPGA. These are available for general communications (flags) or for specific purposes as described below. For more detailed descriptions of signals see [1].

FX2 Port	Port signal number	Function or Signal Name
A	0	FPGA configuration CS_n
	1	FPGA configuration WRITE_n
	2	C_PA2/SLOE – slave output enable
	3	C_PA3/WU2 – 8051 wakeup
	4	C_PA4/FIFOADR0 - slave FIFO address bit 0
	5	C_PA5/FIFOADR1 – slave FIFO address bit 1
	6	C_PA6/PKTEND – slave packet end
	7	C_PA7/FLAGD/SLCS_n – slave FIFO output status flag/slave chip select
B	0-7	FIFO interface data bits 0-7
C	0-7	General purpose bi-directional pins
D	0-7	FIFO interface data bits 8-15
E	0	Enable Power – active low power-on for FPGA, SRAM , etc, which are powered off during USB enumeration (enumeration is the USB initialisation following connection to a computer)
	1	Enable SRAM – active low chip enable for SRAM, can be disabled to conserve power if SRAM is not used
	2	VBUS monitor – monitors VBUS (5V from USB) so 8051 can remove internal pull-up on D+ when VBUS is removed in Full Speed mode (the pull-up is permanently removed in High Speed mode anyway) and the board is powered from J5 or J7
	3	C_PE3
	4	C_PE4
	5	FPGA configuration PROG_n
	6	FPGA configuration INIT_n
	7	FPGA configuration DONE

The GPIF also has 6 Ready input signals and 6 Control output signals for general purpose use, and these are all connected to the FPGA. CTL3 and 4 are connected to FPGA configuration CS_n and WRITE_n. These configuration signals are also connected to Port C bits 0 & 1, but for high speed configuration the GPIF Control signals are used. In Slave FIFO mode some of the Ready and Control signals become FIFO control signals. See table above for Port A signals and table below for Ready and Control signals that are used in Slave FIFO mode.

GPIF Mode	Slave FIFO Mode
RDY0 (I)	SLRD – slave read (I)
RDY1 (I)	SLWR – slave write (I)
RDY2 (I)	
RDY3 (I)	
RDY4 (I)	
RDY5 (I)	
CTL0 (O)	FLAG A (O)
CTL1 (O)	FLAG B (O)
CTL2 (O)	FLAG C (O)
CTL3 (O)	
CTL4 (O)	
CTL5 (O)	

(I) means FX2 input and (O) means FX2 output

7.1.1 Communications with Host

The FPGA uses five means of communication with the FX2 and hence the host computer.

- GPIF mode is used for bulk transfers of FPGA configuration/readback data. Configuration/readback transfers require two endpoints, one for writing and one for reading, making a total of two endpoints. The GPIF has a maximum of four programmable waveforms in its state machine.
- Slave FIFO mode is used for bulk transfers of application data. Application data transfers require two endpoints, one for writing and one for reading, making a total of two endpoints. Transfers using the slave FIFO must be a multiple of 512 bytes in length.
- The 8051 external memory interface is used for access to application registers within the FPGA.
- The 8 bits of Port C of the 8051 are used as general purpose, bi-directional pins. The use of these pins is determined by the user application. They can be used as a simple handshaking protocol, state reporting to the host, control from the host or for any other purpose.
- There is a single interrupt line from the FPGA to the FX2 to allow the FPGA to interrupt the host PC.

See the references [1], [2], [3], [4] and [5] for details on GPIF mode and Slave FIFO mode.

7.1.1.1 FPGA Configuration

The GPIF mode is used for configuring the FPGA using the SelectMap port. The FX2 acts as a master driving the FPGA CS_n, WRITE_n and data ports. Data is transferred directly from the USB port to the GPIF master and on to the FPGA using the Auto Out method detailed in [3].

7.1.1.2 Streaming Data Transfer

The slave FIFO mode is used to stream data between the host and FPGA. The supplied FPGA files include a reference design to illustrate use of the slave FIFO interface to achieve peak transfer rates of 96Mbytes/s and sustained transfer rates only limited by the host PC. The reference design exposes the following signals:

User_CLK	: out std_logic;
User_RST	: out std_logic;
User_StreamBusGrantLength	: in std_logic_vector(11 downto 0);
User_StreamDataIn	: out std_logic_vector(15 downto 0);
User_StreamDataInWE	: out std_logic;
User_StreamDataInBusy	: in std_logic;
User_StreamDataOut	: in std_logic_vector(15 downto 0);
User_StreamDataOutWE	: in std_logic;
User_StreamDataOutBusy	: out std_logic;

Or, in Verilog:

```
output User_CLK,
output User_RST,
input  [11:0] User_StreamBusGrantLength,
output User_StreamDataIn,
output User_StreamDataInWE,
input  User_StreamDataInBusy,
input  [15:0] User_StreamDataOut,
input  User_StreamDataOutWE,
output User_StreamDataOutBusy,
```

User_CLK is a clock output from the core. All signals from the core are synchronous to this clock. All signals to the core should also be synchronous to this clock.

User_RST is an active high global reset output from the core. The user design should use this to reset its state.

User_StreamBusGrantLength is used by the core to fairly arbitrate between transfers to and from the host. The bus between the FX and the FPGA is a 16 bit bidirectional interface and transfers take place in 512 byte blocks (256 sixteen bit words). The FPGA grants the bus to reads or writes for the number of cycles specified by this input before reversing the direction. This is done to avoid deadlock where the host wishes to write to the FPGA and the FPGA wishes to write to the host and to fairly balance reads and writes. Since a bus turnaround takes a number of cycles, this value is a trade-off between peak bandwidth (higher with a larger grant length) and turnaround latency (lower with a lower value). Therefore, for applications which transfer large blocks in one direction before

reversing the data flow, select a large value (256 or greater). For applications which alternate transferring short blocks in either direction, select a short value (such as 16).

`User_StreamDataIn` is the data stream from the host to the FPGA. The active high `User_StreamDataInWE` signal indicates when the data is valid. If the user application sets `User_StreamDataInBusy` high then the host will be blocked and no data will be sent to the user application.

`User_StreamDataOut` is the data stream from the FPGA to the host. The `User_StreamDataOutWE` signal should be set high in the same cycle as the valid data. If the `User_StreamDataOutBusy` signal is high then the user application should not attempt to transfer any more data. The core contains a short FIFO which can accept 4 transfers after `User_StreamDataOutBusy` goes high allowing time for the user application to respond.




Figure 4. Host to FPGA Streaming Cycles




Figure 5. FPGA to Host Streaming Cycles

7.1.1.3 Register Reads and Writes

The FX2 external bus is connected to the FPGA allowing memory mapped accesses to registers implemented inside the FPGA. The supplied FPGA files include a reference design to illustrate use of registers. The reference design exposes the following signals:

User_CLK	: out std_logic;
User_RST	: out std_logic;
User_RegAddr	: out std_logic_vector(15 downto 0);
User_RegDataIn	: out std_logic_vector(7 downto 0);
User_RegDataOut	: in std_logic_vector(7 downto 0);
User_RegWE	: out std_logic;
User_RegRE	: out std_logic;

Or, in Verilog:

```
output User_CLK,
output User_RST,
output [15:0] User_RegAddr,
output [7:0] User_RegDataIn,
input [7:0] User_RegDataOut,
output User_RegWE,
output User_RegRE
```

User_CLK is a clock output from the core. All signals from the core are synchronous to this clock. All signals to the core should also be synchronous to this clock.

User_RST is an active high global reset output from the core. The user design should use this to reset its state.

User_RegAddr is the zero based address of the read or write access. Note that registers between 0x0000 and 0x2000 are not available on boards fitted with the Cypress FX2LP USB controller (part number CY68013A).

User_RegDataIn is the data from the host to the FPGA during a register write.

User_RegDataOut is the data from the FPGA to the host during a register read.

User_RegWE is an active high write strobe. This strobe will be high for a single cycle simultaneously with the address and data.

User_RegRE is an active high read strobe. The user application should return the data on the rising edge of the clock when this strobe is high.




Figure 6. Register read and write accesses

7.1.1.4 User Signals

The 8 user signals between the FPGA and FX2 can be used for any application defined purpose. However, care must be taken to set the direction of the FX2 Port C signals such that the FX2 and FPGA do not drive against each other at any time. Failure to do so may result in damage to the hardware.

7.1.1.5 Host Interrupt

The user core exposes a single signal to interrupt the host.

```
User_Interrupt          : in std_logic;
```

Or, in Verilog:

```
input User_Interrupt
```

Setting `User_Interrupt` high for a single cycle will cause an interrupt on the host which can be trapped by the user application (`ZestSC1WaitForInterrupt()` function).

7.2 FPGA

The FPGA is from the Xilinx Spartan-3 family and is either the XC3S1000-4 or XC3S400-4, according to which was ordered. The package is the FT256 256-pin fine pitch thin BGA.

There are three main devices attached to the FPGA:

- USB controller
- SRAM – 512K x 18 or 4M x 18 of synchronous SRAM

- I/O – 49 I/O signals, 2 of which can be a differential pair clock input. The I/O signals FPGA banks have 51 ohm impedance reference resistors for Spartan DCI buffers.

There are also 8 LEDs D2-9 that share IO signals 0, 1, & 41-46 respectively. These are driven active low.

For signal allocations to FPGA pins, see the UCF supplied with the board.

The FPGA is configured from the USB in Slave Parallel mode. Alternatively it can be configured using JTAG via header J3. The JTAG header on the board is 0.1 inch pitch with pins assigned to align with the Xilinx Parallel Cable Fly Leads. The download cable should be the Xilinx Parallel Cable IV with Parallel Cable Flying Leads. Note that the JTAG reference voltage on pin 1 of J3 is 2.5V.

When using the Xilinx Synthesis Tools XST, the following XST synthesis and implementation properties should be set.

Synthesis Properties – Xilinx Specific Options		
Pack I/O Registers into IOBs		YES
Translate Properties		
Allow Unmatched LOC Constraints		YES
Map Properties		
Allow Logic Optimisation Across Hierarchy		YES
Perform Timing Driven Packing and Placement		YES
Generate Programming File Properties – Configuration Options		
Unused IOB Pins		Pull Up
Generate Programming File Properties – Startup Options		
Drive Done Pin High		YES

7.3 Memory

The memory is NoBL (No Bus Latency, the same as ZBT or Zero Bus Turnaround) pipelined synchronous SRAM from Cypress. The device may be either the 512k x 18 or 4M x 18, according to which was ordered. These devices are respectively the CY7C1356B-166AC [6] and CY7C1472V33-167AC [7].

The SRAM chip enable pin CE1_n is connected to the FX2 Port E bit 1 so that the FX2 can control whether the SRAM is enabled to minimise power consumption. The pin CE1_n has a pull-up so that the SRAM is disabled unless the FX2 enables it by driving this pin low.

MODE, ZZ, CEN_n and CE3_n are all pulled low permanently. CE2 is pulled high permanently.

All other signals are connected to the FPGA, see the UCF for pin connections. The logic core supplied with the board includes interface logic for the SRAM. The user interface is as below.

```

USER_SRAM_A: in std_logic_vector(22 downto 0);    -- 23-bit address
USER_SRAM_W: in std_logic;                        -- write strobe active
                                                    -- high
USER_SRAM_R: in std_logic;                        -- read strobe active
                                                    -- high
USER_SRAM_DR_VALID: out std_logic;                -- read data valid strobe
                                                    -- active high
USER_SRAM_DW: in std_logic_vector(17 downto 0);   -- 18-bit data bus for
                                                    -- writing to SRAM
USER_SRAM_DR: out std_logic_vector(17 downto 0);  -- 18-bit data bus for
                                                    -- reading from SRAM

```

Or, in Verilog:

```

input  [22:0] USER_SRAM_A,           // 23-bit address
input  USER_SRAM_W,                 // write strobe active
                                        // high
input  USER_SRAM_R,                 // read strobe active
                                        // high
output USER_SRAM_DR_VALID,           // read data valid strobe
                                        // active high
input  [17:0] USER_SRAM_DW,          // 18-bit data bus for
                                        // writing to SRAM
output [17:0] USER_SRAM_DR           // 18-bit data bus for
                                        // reading from SRAM

```

The Pipelined ZBT SRAM device takes 2 clock cycles for a write and 2 clock cycles for a read. This logic core has one extra pipeline stage in the write path (giving 3 clock cycles) and two extra pipeline stages in the read path (giving 4 clock cycles). Figure 7 shows the signal waveforms at the user interface.




Figure 7. ZBT SRAM Write and Read Cycles

For write cycles the user logic drives the write strobe high and the write address and data in the same clock cycle. The logic core registers all command and data signals and delays

the data by 2 further clocks as required by the ZBT SRAM. Byte write strobes are not implemented.

For read cycles the user logic drives the read strobe high and the read address in the same clock cycle, and the logic core registers all these signals. Valid data is returned to the user code 4 clocks after the user code drives the read strobe high. The valid data is accompanied by the active high data valid strobe. When the data valid strobe is high then the read data should be registered by the user code.

All accesses are single accesses requiring a valid address with each access, burst accesses are not implemented. There is no difference in bandwidth between single and burst accesses.

The SRAM clock is driven from the FPGA to the SRAM. This must arrive at the SRAM before the command and write data by the SRAM hold time of at least 0.5nS. This is achieved by using a DCM to generate an SRAM clock about 2nS in advance of the User clock and clocking all signals in IOB's. The SRAM clock is used only as an output to the SRAM (via FDDR in IOB) and does not clock any signals in the FPGA.

The data tri-state signal flip-flop is placed in each data IOB to minimize bus contention when changing from write to read or vice versa (see next paragraph). This is achieved by setting the Synthesis property "Pack I/O Registers into IOBs" to YES.

ZBT Zero Bus Turnaround means that there does not have to be an idle cycle between different types of cycles (i.e. writes and reads). The direction of the data bus therefore needs to be able to change just after the start of a clock cycle from one device (e.g. SRAM) driving it to the other device (e.g. FPGA) driving it. Because of differences in turn on and turn off times of the different devices' data bus drivers there will inevitably be some bus contention. However, as [8] shows, bus contention of a few nS is easily tolerable.

7.4 IO

J4 provides user I/O from the FPGA, see the Headers section for the names of signals connected to the pins and the UCF for connections to the FPGA. J4 is a 32 pins x 2 rows 0.1 inch pitch header.

49 pins are connected directly to the FPGA for user I/O. Two of these signals (CLK_IO_P and CLK_IO_N) are connected to clock input pins on the FPGA. They can have a 100 ohm parallel termination resistor across them at the FPGA for a differential clock – see section Build Options. Also signals IO2-45 may be used as differential pairs IO2 & 3, IO4 & 5, ..., IO44 & 45, but they do not have termination resistors on the board.

IO0, 1, 41-46 are also connected to LED's D2 to D9 respectively – see section LED's. An LED is switched on when the IO line is low, and requires 2mA to be drawn by the IO line for full brightness.

There are 6 ground pins at one end of J4 and 7 ground pins at the other end. Pin 1 is 5V power output and pin 2 is 3.3V power output, both via resettable 1.5A fuses. This power can be used for example to power a daughter card plugged onto J4. The 3V3 is from the

power switch so is available only after the FX2 has enabled the power switch using its Port E bit 0.

The FPGA I/O banks connected to J4 are 3V3. **They are NOT 5V tolerant.** However 5V signals can be connected to J4 via 180 ohm series resistors to limit the current into each FPGA pin to less than 10mA.

As a build option, DCI reference resistors can be fitted for matching the characteristic impedance of the IO lines for DCI buffers. The FPGA pins for the reference resistors are the same as IO pins 2, 3, 44 & 45. Hence if the resistors are fitted then these IO pins cannot be used for I/O. Also the FPGA pins for two of the reference resistors are the same as pins connected to LED's D7 and D8. Hence if the resistors are fitted then these LED's are removed.

7.5 LEDs

There is one LED for the FPGA configuration DONE signal, 4 LEDs indicating power supply status, and 8 LEDs connected to the FPGA. These latter 8 LEDs are also connected to IO signals as shown below. Figure 8 shows the positions of the LEDs.

LED	Signal
1	DONE
2	IO0
3	IO1
4	IO41
5	IO42
6	IO43
7	IO44
8	IO45
9	IO46
10	5V
11	3.3V
12	Switched 3.3V
13	2.5V

LED's 2-9 are driven active low. An LED is switched on when the IO line is low, and requires 2mA to be drawn by the IO line for full brightness.

As a build option, DCI reference resistors can be fitted for matching the characteristic impedance of the IO lines for DCI buffers. The FPGA pins for two of the reference resistors are the same as pins connected to LED's D7 and D8. Hence if the resistors are fitted then these LED's are removed.




Figure 8. Approximate Positions of LEDs

7.6 Clocks

The FPGA has two fixed frequency clock inputs of 48MHz each and one clock input from the IO header. The FPGA's internal DCM's can be used to synthesise other clock frequencies from 1.5MHz to 280MHz.

The 48MHz clock for the Slave FIFO Interface connecting the USB controller and the FPGA is driven on separate PCB tracks from a crystal oscillator to the USB controller and to the FPGA. It is connected to FPGA global clock pin GCLK0. It is also used for the FPGA configuration clock CCLK.

The USB controller 8051 clock is output from the USB controller to the FPGA global clock pin GCLK1. The frequency can be set to 12MHz, 24MHz or 48MHz by the 8051, and the 8051 firmware supplied with the ZestSC1 sets it to 48MHz. The logic cores supplied with the board use this USB controller 8051 clock as the main clock. Note this is a separate clock to the 48MHz GPIF clock described in the paragraph above. The host interface logic core includes FIFO's to interface between the two clock domains of the USB controller 8051 clock and the Slave FIFO Interface clock.

The IO clock signals CLK_IO_P and CLK_IO_N are connected to FPGA global clock pins GCLK6 and GCLK7 respectively. They can be configured as single-ended or differential clock inputs.

7.7 Power

The board can be either bus-powered or self-powered. Bus-powered means powered entirely from the USB cable connected to the host computer. **If the board is to be bus-powered then the USB port must be a high power (500mA) port.** The DC/DC converters on the board have been chosen for their very high efficiency of approximately 90%, even at low currents. This is important when the board is bus-powered as only

2.5W (500mA @ nominal 5V) is available from USB. The following table shows the typical quiescent power consumption of the board when connected to a USB host. The remaining power from the USB 2.5W after allowing for 10% loss in the power supplies is available for operating power and is also shown in the table below.

FPGA and Memory	Quiescent Power (W)	Available Operating Power (W)
400 and 1MB	1.35	1.0
1000 and 1MB	1.40	1.0
1000 and 8MB*	1.80	0.6

To minimise power consumption then the following may be done:

- If the SRAM is not required then drive the SRAM clock high or low.
- Do not use internal pull-ups or pull-downs on the FPGA IO pins.

For extra power there are two power connectors for external power supplies to make the board self-powered. One is J5, which is a 2.5mm power jack for connection to a mains power wall adapter. This should be switch mode with low ripple and have an output voltage between 3.5V and 5.5V (nominally 4.5V or 5.0V), an output current of at least 1A, and a female plug inner diameter of 2.5mm. **The plug from the wall adapter should have +5V power on the outside of the pin and ground on the inside of the pin.** When the plug is inserted in the jack, power from USB is disconnected by the jack.

There are 3 resettable fuses fitted to the board at the following points:

- 5V power input from all sources
- 5V power output to I/O header
- 3.3V power output to I/O header

All the fuses are resettable 1.5A fuses. If a fuse trips then disconnect power, remove the fault and wait for the fuse to cool down before reconnecting the power.

Power should be switched off when inserting the mains adapter plug and when changing the position of J6. This is to avoid current surges and voltage ringing in the mains adapter wire.

The other power connector is a PC hard disk drive power connector for connecting to a power cable found inside a PC. J6 is used for selecting either this connector or the power jack/USB power. **J6 should be moved only when all power is off.** The PC hard disk drive power connector is intended for use of the board inside a PC and the board should be mounted securely using the four corner holes and insulating standoffs in a position where it cannot touch any other items such as chassis, boards or cables.

7.8 Build Options

The following modifications can be made to the board by arrangement with Orange Tree Technologies.

1. **DCI reference resistors for the IO lines.** DCI buffers require reference resistors for matching to the characteristic impedance of the IO lines. On ZestSC1 the IO lines are about 50 ohms impedance so the reference resistors are 51 ohms, being the closest standard value. The resistors are connected to the FPGA pins connected to IO2, 3, 44 & 45, so these IO pins cannot be used if the reference resistors are fitted. Also LED's D7 and D8 are connected to IO44 & 45 so these LED's are removed if the reference resistors are fitted. For the standard build the reference resistors are not fitted (so DCI cannot be used) and LED's D7 and D8 are fitted.
2. **IO differential clock input.** IO pins CLK_IO_P and CLK_IO_N are both connected to FPGA clock input pins. They can be used either as separate single ended clocks or general purpose IO or as one differential clock input. A 100 ohm resistor can be fitted at the FPGA pins to terminate a differential clock input. For the standard build this resistor is not fitted.

8 Using the Host Library

The ZestSC1 host support software consists of a system driver and a host library to allow access to the board. The system driver is installed automatically during installation of the ZestSC1 support package. The host library consists of a static C library file (.lib file) and an associated C header file (.h file).

To use the ZestSC1 support library in your own code, you must include the header file at the start of your program. For example:

```
#include <zestsc1.h>
```

The header file must be in your compiler include path. For details of how to set the include path, refer to your compiler manuals.

Your program must then be linked with the ZestSC1.lib library file. For details of how to link additional static libraries, refer to your compiler manuals. You must also link in the standard library 'setupapi.lib' (available in the Windows Platform SDK from Microsoft) which is used by the ZestSC1 host library internal code.

9 Host Utilities

A number of utilities are provided with the ZestSC1 support library. These can be found in the Utils sub-directory of the support package installation.

9.1 Bit2C

Bit2C.exe converts Xilinx .bit FPGA configuration files to C header files. The C header file contains a static array definition with the raw data from the .bit file. This array can be passed to the **ZestSC1RegisterImage** function to obtain a handle suitable for the **ZestSC1Configure** function. In this way, .bit files can be linked into your application executable to avoid having multiple files.

For example:

```
Bit2C config.bit array.c
```

This will convert the **config.bit** file generated by the Xilinx place and route tools into a file called **array.c** which contains definitions of the variables **arrayLength** and **arrayImage**. You can then configure the FPGA by calling the following functions:

```
extern void *arrayImage;
extern unsigned long arrayLength;
ZESTSC1_IMAGE Image;
ZESTSC1_HANDLE Handle;

/* Register the FPGA configuration image */
ZestSC1RegisterImage(arrayImage, arrayLength, &Image);

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);
/* Configure the FPGA from the image */
ZestSC1Configure(Handle, Image);
```

9.2 SetID

Each ZestSC1 card contains a non-volatile ID to allow identification of the card in a system with multiple ZestSC1's attached. The ID is passed to the ZestSC1OpenCard function to obtain a handle to the card.

For example, a system may consist of a ZestSC1 card attached to a camera and a second ZestSC1 connected to a monitor. Setting the ID of the first card to 1 and the second card to 2 will allow the host program to distinguish between the two cards.

SetID.exe programs the ID of a card from the command line. Run SetID.exe from a command prompt and follow the on-screen instructions.

10 Examples

The ZestSC1 Support package contains a number of examples to illustrate the use of the ZestSC1 and its Host Support Library. The examples are located in the Examples sub-directory of the ZestSC1 installation directory. Each example consists of a host program and a Xilinx XST VHDL or Verilog project.

Examples 2 and 4 also contain ModelSim testbenches to illustrate how the various interfaces can be simulated before implementation.

Example1 shows how to configure the FPGA from a .bit file generated by the Xilinx place and route tools. The .bit file flashes the LEDs on the board in sequence.

Example2 shows how to use the high-speed streaming interface on the ZestSC1 by measuring data transfer rates between the FPGA and the host in either direction. The VHDL/Verilog code implements an infinite data sink and an infinite data source to illustrate use of the VHDL/Verilog support library.

Example3 shows how to use the low-speed control interface on the ZestSC1 by reading and writing a memory-mapped register and reading and writing the single bit signals. The VHDL/Verilog code implements a number of read/write registers and a loop-back of 4 input signals to 4 output signals.

Example4 shows how to use the SRAM on the ZestSC1. The VHDL/Verilog code implements a DMA engine between the USB streaming port and the SRAM allowing the host to read and write blocks of data.

11 Host Library Function Reference

ZestSC1CountCards

```
ZESTSC1_STATUS ZestSC1CountCards( unsigned long *NumCards,  
                                     unsigned long *CardIDs,  
                                     unsigned long *SerialNumbers,  
                                     ZESTSC1_FPGA_TYPE *FPGATypes);
```

Parameters

<i>NumCards</i>	Pointer to location to receive total number of ZestSC1 cards in the system.
<i>CardIDs</i>	Pointer to buffer to receive list of card IDs in the system. May be NULL.
<i>SerialNumbers</i>	Pointer to buffer to receive list of card serial numbers in the system. May be NULL.
<i>FPGATypes</i>	Pointer to buffer to receive list of FPGA types fitted to cards in the system. May be NULL.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver

Description

ZestSC1CountCards can be used to determine the number and types of cards fitted in a system. Each card can be identified in 3 ways: by a user-programmable card ID, by a factory set unique serial number and by the type of FPGA fitted to the card.

CardIDs should point to the start of an array which will be filled in with the user programmable card IDs. See **ZestSC1SetCardID** for details of how to set this ID. This ID should be passed to **ZestSC1OpenCard** to obtain a handle for accessing the selected ZestSC1 card.

SerialNumbers should point to the start of an array which will be filled in with the factory set, unique serial number of the cards in the system.

FPGATypes should point to the start of an array which will be filled in with the type of FPGA fitted.

Each of these arrays should be large enough to receive values for each of the cards in the system. Any or all of them can be NULL if the information is not required. A call to **ZestSC1CountCards** can be made with NULL pointers to determine the size of the required array as follows:

```
unsigned long NumCards;
unsigned long *CardIDs;

/* Get the number of cards in the system */
ZestSC1CountCards(&NumCards, NULL, NULL, NULL);

/* Allocate a buffer to receive the card IDs */
CardIDs = malloc(sizeof(unsigned long) * NumCards);

/* Fill in the buffer with the card IDs */
ZestSC1CountCards(&NumCards, CardIDs, NULL, NULL);
```

ZestSC1OpenCard

```
ZESTSC1_STATUS ZestSC1OpenCard(  unsigned long CardID,  
                                ZESTSC1_HANDLE *Handle);
```

Parameters

<i>CardId</i>	ID of card to open. See ZestSC1CountCards .
<i>Handle</i>	Pointer to receive the handle of the open card. This handle is used to identify the card in future calls to the ZestSC1 library.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_OUT_OF_MEMORY	Not enough memory to complete the requested operation
ZESTSC1_ILLEGAL_CARD_ID	The requested card ID does not correspond to any devices in the system

Description

ZestSC1OpenCard is used to obtain a handle to a card in the system for future calls to ZestSC1 library functions. The card is identified by a user-programmable ID. See **ZestSC1CountCards** for details of how to find the IDs of cards in the system and **ZestSC1SetCardID** for details of how to set this ID.

For example:

```
ZESTSC1_HANDLE Handle;  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Configure the FPGA on the open card */  
ZestSC1ConfigureFromFile(Handle, "test.bit");
```

ZestSC1CloseCard should be called to free the card before the program exits.

ZestSC1GetCardInfo

ZESTSC1_STATUS ZestSC1GetCardInfo(**ZESTSC1_HANDLE** Handle,
ZESTSC1_CARD_INFO *Info);

Parameters

Handle Handle of open ZestSC1 card. See **ZestSC1OpenCard**.
Info Pointer to structure to receive information about the card.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1GetCardInfo can be used to obtain information about an open card. The **ZESTSC1_CARD_INFO** structure is defined as follows:

```
typedef struct
{
    unsigned long CardID;
    unsigned long SerialNumber;
    ZESTSC1_FPGA_TYPE FPGAType;
    Unsigned long MemorySize;
    unsigned long TimeOut;
} ZESTSC1_CARD_INFO;
```

CardID is a user-programmable ID for the card. See **ZestSC1CountCards** for details of how to find the IDs of cards in the system and **ZestSC1SetCardID** for details of how to set this ID.

SerialNumber is a unique, factory-set serial number for the card.

FPGAType gives the type of FPGA fitted to the card.

MemorySize gives the number of bytes of SRAM fitted to the card.

TimeOut is the length of time, in milliseconds, that blocking operations should wait for before returning **ZESTSC1_TIMEOUT**. Time outs allow the user program to recover cleanly when communication with the card fails. See **ZestSC1SetTimeOut** for details of how to set this time.

For example:

```
ZESTSC1_HANDLE Handle;
```

```
ZESTSC1_CARD_INFO Info;

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Obtain information about the card */
ZestSC1GetCardInfo(Handle, &Info);

/* Perform action based on FPGAType */
if (Info.FPGAType==ZESTSC1_XC3S400)
    ZestSC1ConfigureFromFile(Handle, "file400.bit");
else if (Info.FPGAType== ZESTSC1_XC3S1000)
    ZestSC1ConfigureFromFile(Handle, "file1000.bit");
else
    printf(Illegal FPGA type\n");
```


ZestSC1SetTimeOut

ZESTSC1_STATUS ZestSC1SetTimeOut(**ZESTSC1_HANDLE** Handle,
unsigned long MilliSeconds);

Parameters

<i>Handle</i>	Handle of open ZestSC1 card. See ZestSC1OpenCard .
<i>MilliSeconds</i>	Length to required timeout in milliseconds.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle

Description

ZestSC1SetTimeOut can be used to set the length of time, in milliseconds, that blocking operations should wait for before returning **ZESTSC1_TIMEOUT**. Time outs allow the user program to recover cleanly when communication with the card fails. The default length of the time out is 10 seconds.

For example:

```
ZESTSC1_HANDLE Handle;

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Set the time out to 20 seconds */
ZestSC1SetTimeOut(Handle, 20000);

/* Perform action and time out if card doesn't
respond within 20 seconds */
if (ZestSC1ConfigureFromFile(Handle, "test.bit")==ZESTSC1_TIMEOUT)
    printf("Failed to configure FPGA - time out\n");
```

ZestSC1SetCardID

ZESTSC1_STATUS ZestSC1SetCardID(**ZESTSC1_HANDLE** *Handle*,
unsigned long *CardID*);

Parameters

<i>Handle</i>	Handle of open ZestSC1 card. See ZestSC1OpenCard .
<i>CardID</i>	Value of new card ID.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1SetCardID can be used to set the user-programmable ID of a card in the system. This ID is then used to identify the card in future calls to **ZestSC1OpenCard**.

The card ID is a useful way to allow software to be written in a platform independent way. For example, suppose a system has 3 cards with different peripherals attached to the front panel connector. The card ID can be set on each card to allow the software to identify the cards based on the attached peripherals. A second copy of the system can be constructed with the same set of card IDs so the software can be written so that it runs on either copy of the system.

For example:

```
ZESTSC1_HANDLE Handle;  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Set card ID to 23 */  
ZestSC1SetCardID(Handle, 23);  
  
/* Close the card */  
ZestSC1CloseCard(Handle);  
  
/* Re-open the card but with ID of 23 */  
ZestSC1OpenCard(23, &Handle);
```

ZestSC1CloseCard

ZESTSC1_STATUS ZestSC1CloseCard(ZESTSC1_HANDLE Handle);

Parameters

Handle Handle of open ZestSC1 card to close. See **ZestSC1OpenCard**.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1CloseCard should be called when the specified card is finished with. It frees resources and allows other applications to access the card.

For example:

```
ZESTSC1_HANDLE Handle;

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Other calls to ZestSC1 library here */

/* Close the card */
ZestSC1CloseCard(Handle);
```

ZestSC1RegisterErrorHandler

```
ZESTSC1_STATUS ZestSC1RegisterErrorHandler(  
                                ZESTSC1_ERROR_FUNC Function);
```

Parameters

Function Pointer to error handler function to receive all error notifications for this application.

Return Value

ZESTSC1_SUCCESS Function succeeded

Description

ZestSC1RegisterErrorHandler can be called to install a central error handling routine for a user program. If any of the following ZestSC1 library function calls fail, the user error handler will be called giving details of the failure. This mechanism means that status codes need not be checked for every library call which simplifies code considerably.

ZESTSC1_ERROR_FUNC is a function declared as follows:

```
typedef void (*ZESTSC1_ERROR_FUNC) (const char *Function,  
                                     ZESTSC1_HANDLE Handle,  
                                     ZESTSC1_STATUS Status,  
                                     const char *Msg);
```

Function is a string containing the name of the function that failed. *Handle* is the handle of the card being accessed at the time of the failure. This may be NULL for functions that do not take a card handle. *Status* is the status code describing the failure and *Msg* is a string describing the failure.

For example:

```
/* Error handler function */  
void ErrorHandler(const char *Function,  
                 ZESTSC1_HANDLE Handle,  
                 ZESTSC1_STATUS Status,  
                 const char *Msg)  
{  
    printf("**** Function %s returned an error\n", Function);  
    printf("**** 0x%08lx : \"%s\"\n\n", Status, Msg);  
    exit(1);  
}  
  
void main(void)  
{  
    ZestSC1RegisterErrorHandler(ErrorHandler);
```

```
/* Other calls to ZestSC1 library here */  
/* Note that the return code need not be checked  
   as ErrorHandler will be called for any return values  
   not equal to ZESTSC1_SUCCESS */  
  
}
```

ZestSC1GetErrorMessage

```
ZESTSC1_STATUS ZestSC1GetErrorMessage(ZESTSC1_STATUS Status,  
                                       char **Buffer);
```

Parameters

<i>Status</i>	ZestSC1 error code for which description is required.
<i>Buffer</i>	Pointer to location to receive error code description string.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_STATUS_CODE	Status code is out of range

Description

ZestSC1GetErrorMessage can be called to obtain a descriptive message for a return status from a ZestSC1 library function. On return, the string pointed to by *Buffer* will be a description of the *Status* return code. This is a static string and so does not need to be freed.

For example:

```
ZESTSC1_HANDLE Handle;  
ZESTSC1_STATUS Status;  
  
/* Open a card with ID of 1 */  
Status = ZestSC1OpenCard(1, &Handle);  
  
if (Status!=ZESTSC1_SUCCESS)  
{  
    char *Buffer;  
  
    ZestSC1GetErrorMessage(Status, &Buffer);  
    printf("Error : %s\n", Buffer);  
}
```

ZestSC1ConfigureFromFile

ZESTSC1_STATUS ZestSC1ConfigureFromFile(**ZESTSC1_HANDLE** Handle,
char *FileName);

Parameters

Handle Handle of open ZestSC1 card. See **ZestSC1OpenCard**.
FileName Name of .bit file to use to configure the FPGA.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_NULL_PARAMETER	NULL was used illegally as one of the parameter values
ZESTSC1_FILE_NOT_FOUND	File not found
ZESTSC1_FILE_ERROR	Error while reading file
ZESTSC1_OUT_OF_MEMORY	Not enough memory to complete the requested operation
ZESTSC1_ILLEGAL_FILE	File format is not recognised
ZESTSC1_INVALID_PART_TYPE	Illegal FPGA part type
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1ConfigureFromFile can be used to configure the FPGA on the ZestSC1 card from a .bit file generated by the Xilinx place and route software. It configures the FPGA directly from the file on disk. Refer to **ZestSC1RegisterImage** and **ZestSC1Configure** for details of how to configure the FPGA from configuration data in memory.

For example:

```
ZESTSC1_HANDLE Handle;

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Configure the FPGA from a .bit file */
ZestSC1ConfigureFromFile(Handle, "test.bit");
```



Configuring the FPGA with an incorrect BIT file can damage your hardware. Ensure that FPGA pins are connected correctly and do not drive against peripherals on the board.

ZestSC1LoadFile

ZESTSC1_STATUS ZestSC1LoadFile(**char *FileName,**
 ZESTSC1_IMAGE *Image);

Parameters

<i>FileName</i>	Name of .bit file to use to configure the FPGA.
<i>Image</i>	Pointer to location to receive FPGA configuration image.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_NULL_PARAMETER	NULL was used illegally as one of the parameter values
ZESTSC1_FILE_NOT_FOUND	File not found
ZESTSC1_FILE_ERROR	Error while reading file
ZESTSC1_OUT_OF_MEMORY	Not enough memory to complete the requested operation
ZESTSC1_ILLEGAL_FILE	File format is not recognised
ZESTSC1_INVALID_PART_TYPE	Illegal FPGA part type

Description

ZestSC1LoadFile can be used to load a .bit file generated by the Xilinx place and route software into memory for future configuration of the FPGA on the ZestSC1 card. It is possible to load many configuration files during initialization and select the correct FPGA image to use during execution of the program. This reduces overhead at configuration time.

Image is a pointer to a location to receive the configuration image handle. This handle can be used in future calls to **ZestSC1Configure**. The handle should be freed by calling **ZestSC1FreeImage** when the configuration image is no longer needed.

ZestSC1LoadFile and **ZestSC1Configure** allow decoupled loading of the bit file and configuration of the FPGA. Refer to **ZestSC1RegisterImage** and **ZestSC1Configure** for details of how to configure the FPGA from configuration data in memory.

For example:

```
ZESTSC1_IMAGE Image;
ZESTSC1_HANDLE Handle;

/* Load the .bit file */
ZestSC1LoadImage("test.bit", &Image);

/* Other initialization operations here */

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);
```

```
/* Other execution operations here */  
  
/* Configure the FPGA from the image */  
ZestSC1Configure(Handle, Image);
```

ZestSC1Configure

ZESTSC1_STATUS ZestSC1Configure(**ZESTSC1_HANDLE** *Handle*,
 ZESTSC1_IMAGE *Image*);

Parameters

Handle Handle of open ZestSC1 card. See **ZestSC1OpenCard**.
Image FPGA configuration image to use to configure the FPGA.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_ILLEGAL_IMAGE_HANDLE	Attempt to use illegal configuration image handle
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1Configure configures the FPGA on the ZestSC1 card from a configuration image. The configuration image can be created from a .bit file by calling **ZestSC1LoadImage** or from data in memory by calling **ZestSC1RegisterImage**.

Example creating the image from .bit file on disk:

```
ZESTSC1_IMAGE Image;
ZESTSC1_HANDLE Handle;

/* Load the .bit file */
ZestSC1LoadImage("test.bit", &Image);

/* Other initialization operations here */

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Other execution operations here */

/* Configure the FPGA from the image */
ZestSC1Configure(Handle, Image);
```

Example creating the image from buffer in memory:

```
extern void *Buffer;
extern unsigned long Length;
ZESTSC1_IMAGE Image;
ZESTSC1_HANDLE Handle;
```

```
/* Register the FPGA configuration image */
ZestSC1RegisterImage(Buffer, Length, &Image);

/* Other initialization operations here */

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Other execution operations here */

/* Configure the FPGA from the image */
ZestSC1Configure(Handle, Image);
```



Configuring the FPGA with an incorrect BIT file can damage your hardware. Ensure that FPGA pins are connected correctly and do not drive against peripherals on the board.

ZestSC1RegisterImage

```
ZESTSC1_STATUS ZestSC1RegisterImage(void *Buffer,
                                     unsigned long BufferLength,
                                     ZESTSC1_IMAGE *Image);
```

Parameters

<i>Buffer</i>	Buffer containing FPGA configuration data. Normally generated by Bit2C utility.
<i>BufferLength</i>	Length, in bytes, of the configuration data.
<i>Image</i>	Pointer to location to receive FPGA configuration image.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_OUT_OF_MEMORY	Not enough memory to complete the requested operation
ZESTSC1_INVALID_PART_TYPE	Illegal FPGA part type

Description

ZestSC1RegisterImage creates an FPGA configuration image from an array of raw configuration data. The FPGA can be configured from this image by calling **ZestSC1Configure**.

Buffer points to the start of the raw configuration data and *BufferLength* is the number of bytes of configuration data to use. The Bit2C utility supplied on the ZestSC1 installation disk provides a simple way to generate compatible C arrays from .bit files.

Image is a pointer to a location to receive the configuration image handle. This handle can be used in future calls to **ZestSC1Configure**. The handle should be freed by calling **ZestSC1FreeImage** when the configuration image is no longer needed.

ZestSC1RegisterImage and **ZestSC1Configure** allow .bit files to be linked into host executables to reduce the number of host files required. Refer to **ZestSC1ConfigureFromFile**, **ZestSC1LoadImage** and **ZestSC1Configure** for details of how to configure the FPGA from configuration data in a file.

For example:

```
extern void *Buffer;
extern unsigned long Length;
ZESTSC1_IMAGE Image;
ZESTSC1_HANDLE Handle;

/* Register the FPGA configuration image */
ZestSC1RegisterImage(Buffer, Length, &Image);

/* Other initialization operations here */
```

```
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Other execution operations here */  
  
/* Configure the FPGA from the image */  
ZestSC1Configure(Handle, Image);
```

ZestSC1FreeImage

ZESTSC1_STATUS ZestSC1FreeImage(ZESTSC1_IMAGE Image);

Parameters

Image FPGA configuration image to free.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_IMAGE_HANDLE	Attempt to use illegal configuration image handle

Description

ZestSC1FreeImage should be called when a configuration image handle is no longer needed. It is used to free resources allocated during **ZestSC1LoadImage** and **ZestSC1RegisterImage** functions.

For example:

```
extern void *Buffer;
extern unsigned long Length;
ZESTSC1_IMAGE Image;
ZESTSC1_HANDLE Handle;

/* Register the FPGA configuration image */
ZestSC1RegisterImage(Buffer, Length, &Image);

/* Other initialization operations here */

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Other execution operations here */

/* Configure the FPGA from the image */
ZestSC1Configure(Handle, Image);

/* Free resources associated with the handle */
ZestSC1FreeImage(Image);
```

ZestSC1ReadRegister

ZESTSC1_STATUS ZestSC1ReadRegister(**ZESTSC1_HANDLE** Handle,
unsigned long Offset,
unsigned char *Value);

Parameters

<i>Handle</i>	Handle of open ZestSC1 card. See ZestSC1OpenCard .
<i>Offset</i>	Address of register in FPGA.
<i>Value</i>	Pointer to location to receive register value.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_NULL_PARAMETER	NULL was used illegally as one of the parameter values
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1ReadRegister returns the value of a register from the memory-mapped interface on the ZestSC1 card FPGA.

Boards fitted with the Cypress FX2 USB controller chip (part number CY7C68013) allow an offset of 0x0000 to 0x8000. Boards fitted with the Cypress FX2LP USB controller chip (part number CY7C68013A) allow an offset of 0x2000 to 0x6000.

For example:

```
ZESTSC1_HANDLE Handle;  
char Value;  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Get value of register 0 from board */  
ZestSC1ReadRegister(Handle, 0, &Value);  
  
/* Close the card */  
ZestSC1CloseCard(Handle);
```



Attempting to transfer data to/from the FPGA without a suitable slave interface configured may result in the ZestSC1 'hanging'.

ZestSC1ReadData

ZESTSC1_STATUS ZestSC1ReadData(**ZESTSC1_HANDLE** *Handle*,
 void **Buffer*,
 unsigned long *Length*);

Parameters

<i>Handle</i>	Handle of open ZestSC1 card. See ZestSC1OpenCard .
<i>Buffer</i>	Buffer to receive the data.
<i>Length</i>	Number of bytes to transfer. Must be a multiple of 512.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_NULL_PARAMETER	NULL was used illegally as one of the parameter values
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1ReadData transfers data from the ZestSC1 card streaming interface to the Host. Data transfers over the streaming interface must be a multiple of 512 bytes in length.

For example:

```
ZESTSC1_HANDLE Handle;  
char Buffer[1024];  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Transfer 1k from board to host */  
ZestSC1ReadData(Handle, Buffer, 1024);  
  
/* Close the card */  
ZestSC1CloseCard(Handle);
```



Attempting to transfer data to/from the FPGA without a suitable slave interface configured may result in the ZestSC1 'hanging'.

ZestSC1WriteData

ZESTSC1_STATUS ZestSC1WriteData(**ZESTSC1_HANDLE** Handle,
void *Buffer,
unsigned long Length);

Parameters

<i>Handle</i>	Handle of open ZestSC1 card. See ZestSC1OpenCard .
<i>Buffer</i>	Buffer of data to write.
<i>Length</i>	Number of bytes to transfer. Must be a multiple of 512.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_NULL_PARAMETER	NULL was used illegally as one of the parameter values
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1WriteData transfers data from the Host to the ZestSC1 card streaming interface. Data transfers over the streaming interface must be a multiple of 512 bytes in length.

For example:

```
ZESTSC1_HANDLE Handle;
char Buffer[1024];

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Transfer 1k from host to board */
ZestSC1WriteData(Handle, Buffer, 1024);

/* Close the card */
ZestSC1CloseCard(Handle);
```



Attempting to transfer data to/from the FPGA without a suitable slave interface configured may result in the ZestSC1 'hanging'.

ZestSC1SetSignalDirection

ZESTSC1_STATUS ZestSC1SetSignalDirection(**ZESTSC1_HANDLE** *Handle*,
unsigned char *Direction*);

Parameters

<i>Handle</i>	Handle of open ZestSC1 card. See ZestSC1OpenCard .
<i>Direction</i>	Mask of bits for signal direction. A 1 bit indicates a signal from host to FPGA.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out
ZESTSC1_ILLEGAL_SIGNAL_MASK	The requested mask specifies signals not available on this card

Description

The ZestSC1 card has 8 general purpose signals routed between host and FPGA. Each of these signals can be either a general signal from host to FPGA or from FPGA to host. **ZestSC1SetSignalDirection** controls which of these functions is assigned to each of the 8 signals.

Direction is an 8 bit mask where bit 0 controls GPP0, bit 1 controls GPP1, bit 2 controls GPP2 and so on. Each bit should be set to 1 for the signal to be host to FPGA and 0 for the signal to be FPGA to host. Signals from host to FPGA can be controlled by calling **ZestSC1SetSignals**. The host can read signals from the FPGA by calling **ZestSC1ReadSignals**.

Since the 8 general purpose signals are connected to pins on the FPGA, it is important that conflicts do not arise where both the USB interface chip and the FPGA are driving the same wire. To prevent damage to the ZestSC1 card, it is crucial that signals set to the host to FPGA direction (1 in the *Direction* bit mask) are never driven by the FPGA. Note that all FPGA pins are tri-stated when the FPGA is unconfigured so it is safe to set the signal direction before configuration.

For example:

```
ZESTSC1_HANDLE Handle;  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Set GPP0 to be host to FPGA */  
ZestSC1SetSignalDirecion(Handle, 1);
```

```
/* Configure the FPGA */  
ZestSC1ConfigureFromFile(Handle, "example.bit");  
  
/* Set the signal to 'active' */  
ZestSC1SetSignals(Handle, 1);  
  
/* Set the signal to 'inactive' */  
ZestSC1SetSignals(Handle, 0);  
  
/* Close the card */  
ZestSC1CloseCard(Handle);
```



Driving a signal from both the host and FPGA may damage the ZestSC1 hardware.

ZestSC1SetSignals

ZESTSC1_STATUS ZestSC1SetSignals(**ZESTSC1_HANDLE** *Handle*,
unsigned char *Value*);

Parameters

Handle Handle of open ZestSC1 card. See **ZestSC1OpenCard**.
Value Mask of bits to set.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out
ZESTSC1_ILLEGAL_SIGNAL_MASK	The requested mask specifies signals not available on this card
ZESTSC1_SIGNAL_IS_INPUT	One of the requested signals is an input and cannot be set

Description

ZestSC1SetSignals controls the value of general purpose signals from host to FPGA. *Value* is an 8 bit mask where bit 0 controls GPP0, bit 1 controls GPP1, bit 2 controls GPP2 and so on.

Each signal asserted by this function must have been set up as a host to FPGA signal by **ZestSC1SetSignalDirection** prior to calling **ZestSC1SetSignals**.

Since the 8 general purpose signals are connected to pins on the FPGA, it is important that conflicts do not arise where both the USB interface chip and the FPGA are driving the same wire. To prevent damage to the ZestSC1 card, it is crucial that signals set to the host to FPGA direction (1 in the *Direction* bit mask) are never driven by the FPGA. Note that all FPGA pins are tri-stated when the FPGA is unconfigured so it is safe to set the signal direction before configuration.

For example:

```
ZESTSC1_HANDLE Handle;  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Set GPP0 to be host to FPGA */  
ZestSC1SetSignalDirection(Handle, 1);  
  
/* Configure the FPGA */  
ZestSC1ConfigureFromFile(Handle, "example.bit");
```

```
/* Set the signal to 'active' */  
ZestSC1SetSignals(Handle, 1);  
  
/* Set the signal to 'inactive' */  
ZestSC1SetSignals(Handle, 0);  
  
/* Close the card */  
ZestSC1CloseCard(Handle);
```



Driving a signal from both the host and FPGA may damage the ZestSC1 hardware.

ZestSC1ReadSignals

ZESTSC1_STATUS ZestSC1ReadSignals(**ZESTSC1_HANDLE** *Handle*,
unsigned char **Value*);

Parameters

Handle Handle of open ZestSC1 card. See **ZestSC1OpenCard**.
Value Pointer to location to receive active signals.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out
ZESTSC1_ILLEGAL_SIGNAL_MASK	The requested mask specifies signals not available on this card
ZESTSC1_SIGNAL_IS_OUTPUT	One of the requested signals is an output and cannot be read

Description

ZestSC1ReadSignals can be used to read the value of signals from FPGA to host. *Value* is an 8 bit mask of the signal values where bit 0 is GPP0, bit 1 is GPP1, bit 2 is GPP2 and so on. All signals of interest should be configured as FPGA to host signals by **ZestSC1SetSignalDirection**.

For example:

```
ZESTSC1_HANDLE Handle;  
unsigned long Value;  
  
/* Open a card with ID of 1 */  
ZestSC1OpenCard(1, &Handle);  
  
/* Set GPP0 to be FPGA to host */  
ZestSC1SetSignalDirecion(Handle, 0);  
  
/* Configure the FPGA */  
ZestSC1ConfigureFromFile(Handle, "example.bit");  
  
/* Wait for the signal to become 'active' */  
do  
{  
    ZestSC1ReadSignals(Handle, 1, &Value);  
} while ((Value&1)==0);  
  
/* Close the card */  
ZestSC1CloseCard(Handle);
```


ZestSC1WaitForInterrupt

ZESTSC1_STATUS ZestSC1WaitForInterrupt(ZESTSC1_HANDLE Handle);

Parameters

Handle Handle of open ZestSC1 card. See **ZestSC1OpenCard**.

Return Value

ZESTSC1_SUCCESS	Function succeeded
ZESTSC1_ILLEGAL_HANDLE	Attempt to use illegal card handle
ZESTSC1_INTERNAL_ERROR	An unspecified internal error occurred while communicating with the driver
ZESTSC1_TIMEOUT	Operation timed out

Description

ZestSC1WaitForInterrupt can be used to wait for the FPGA to interrupt the host. Interrupts could be used to indicate the FPGA is ready for data or has completed an operation or any other event that the host must wait for. The FPGA raises an interrupt by asserting the `User_Interrupt` signal (see section 7.1.1.5).

For example:

```
ZESTSC1_HANDLE Handle;

/* Open a card with ID of 1 */
ZestSC1OpenCard(1, &Handle);

/* Configure the FPGA */
ZestSC1ConfigureFromFile(Handle, "example.bit");

/* Wait for interrupt */
ZestSC1WaitForInterrupt(Handle);

/* Close the card */
ZestSC1CloseCard(Handle);
```